



### CR605 Parts List

Part No.	Description	Quantity	Part No.	Description	Quantity
1	Screw ST4.2×33.5	8	26	Connect wire	1
2	Plastic cover	1	27	Drum	1
3	Termination 6.3	2	28	Spring	1
4	Thermal cut-out	1	29	Drum	1
5	Connect wire	1	30	Screw ST4.2×19	4
6	Screw ST2.9×9.5	4	31	Axle	1
7	Cable clamp	2	32	Ratchet axle	1
8	Screw ST2.9×14	2	33	Ratchet paw	1
9	Terminal block	2	34	Spring	1
10	Screw M5×25	2	35	Bracket	1
11	Cover	1	36	Cover	1
12	Pin	2	37	Nut M5	2
13	Roller	2	38	Plastic cover	1
14	Shrinkable tube	3	39	Slip ring	1
15	Connect wire	1	40	Slip ring	1
16	Connect wire	1	41	Slip ring	1
17	Connect wire	1	42	Half copper ring	1
18	Fixed plate	1	43	Half copper ring	1
19	Touch slice	6	44	Half copper ring	1
20	Copper rivet	6	45	Stop block	2
21	Screw ST4.2×22	3	46	Inlet, flexible cable	1
22	Movable plate	1	47	Screw ST4.2×16	1
23	Termination 4.8	3	48	Outlet, flexible cable	1
24	Connect wire	1	49	Protect sheath	1
25	Connect wire	1			